

12-01-2025

Software update instruction from 2.10 to 2.12

The version 2.12 upgrades the GPS memory from 20 positions to 100 positions, using 5 memory banks.

Step 1: use the K22 DPV Windows app to connect to the compass (menu->reset and update-> connect to computer) and download the GPS positions from the compass. Save this file with a specific name. The current GPS entries will otherwise be overwritten by the software upgrade.

Step 2: in the K22 Windows app; choose 3rd tab: Update firmware. Select the new software version from your PC (V2.12) Start upload.

Wait until the upload is complete. Power cycle the compass.

The compass will create new 5 banks of memory locations to store GPS. In the compass display this message appears: "Creating new GPS storing locations"

Press ok-> counts up from 10% to 100% When finished: the display shows: done!

Via menu-> GPS a new row is added: Select memory bank. Here you can select the memory bank you want to use.

load GPS is now shows in the top row: bank 1 1 of 4(pages)

Via the K22 Windows app the memory banks can be filled with separate files.

When a bank is chosen, it will start up with this bank number after a power cycle. While diving, memory banks can be switched.